

FORM  
6  
Rev  
12/05

# State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

**Replug By Other Operator**

Document Number:

401607584

Date Received:

## WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10625 Contact Name: Stephen Miller  
 Name of Operator: HIGHLANDS NATURAL RESOURCES Phone: (361) 2309375  
 Address: 220 JOSEPHINE STREET Fax: \_\_\_\_\_  
 City: DENVER State: CO Zip: 80206 Email: stephen.miller@highlandsnr.com

**For "Intent" 24 hour notice required,** Name: Sherman, Susan Tel: (719) 775-1111  
 COGCC contact: Email: susan.sherman@state.co.us

API Number 05-005-06602-00  
 Well Name: SMOKEY HILL-STATE Well Number: 4-22  
 Location: QtrQtr: NWNW Section: 22 Township: 5S Range: 64W Meridian: 6  
 County: ARAPAHOE Federal, Indian or State Lease Number: 70-8012/S  
 Field Name: WILDCAT Field Number: 99999

Notice of Intent to Abandon  Subsequent Report of Abandonment

### Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.606455 Longitude: -104.545888  
 GPS Data:  
 Date of Measurement: \_\_\_\_\_ PDOP Reading: \_\_\_\_\_ GPS Instrument Operator's Name: \_\_\_\_\_  
 Reason for Abandonment:  Dry  Production Sub-economic  Mechanical Problems  
 Other Re-Enter to Re-Plug by Other Operator.  
 Casing to be pulled:  Yes  No Estimated Depth: 8377  
 Fish in Hole:  Yes  No If yes, explain details below  
 Wellbore has Uncemented Casing leaks:  Yes  No If yes, explain details below  
 Details:

Purpose is to re-enter and adequately re-plug prior to hydraulic fracturing of wells on the Highlands 15/16 Pad location (449920).

1. Evacuate around wellbore
2. Clean and weld on stub to the 8-5/8" Casing
3. Install bowl and BOPs and closed loop system.
4. Drill out cement and wash down with stiff BHA to 8262'
5. Spot plug from 8262' - 7900' with class G Cement (90 sks) and tag once set.
6. Spot plug from 7750' - 7128' with class G Cement (160 sks) and tag once set.
7. Spot plug from 2030' - 1780' (below Fox Hills) with class G Cement (75 sks) and tag once set.
8. Spot plug from 1463' - 1293' (below Arapahoe) with class G Cement (50 sks), no tag.
9. Spot plug from 950' - 700' with class G Cement (50 sks), no tag.
10. Set 75 sks half in - half out of surface casing 250 ft to surface.
11. Cut off 4' below ground and weld on plate showing well details.

9. Spot plug from 950' - 700' with class G Cement (50 sks), no tag.
10. Set 75 sks half in - half out of surface casing 250 ft to surface.
11. Cut off 4' below ground and weld on plate showing well details.

### Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

### Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	201	150	201	0	VISU
OPEN HOLE	7+7/8			8,377				

### Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

CIBP #3: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top. CIBP #4: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

CIBP #5: Depth \_\_\_\_\_ with \_\_\_\_\_ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 90 sks cmt from 8262 ft. to 7900 ft. Plug Type: OPEN HOLE Plug Tagged:

Set 160 sks cmt from 7750 ft. to 7128 ft. Plug Type: OPEN HOLE Plug Tagged:

Set 75 sks cmt from 2030 ft. to 1780 ft. Plug Type: OPEN HOLE Plug Tagged:

Set 50 sks cmt from 1463 ft. to 1293 ft. Plug Type: OPEN HOLE Plug Tagged:

Set 50 sks cmt from 950 ft. to 700 ft. Plug Type: OPEN HOLE Plug Tagged:

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

Perforate and squeeze at \_\_\_\_\_ ft. with \_\_\_\_\_ sacks. Leave at least 100 ft. in casing \_\_\_\_\_ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 75 sacks half in. half out surface casing from 250 ft. to 0 ft. Plug Tagged:

Set \_\_\_\_\_ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker:  Yes  No

Set \_\_\_\_\_ sacks in rat hole Set \_\_\_\_\_ sacks in mouse hole

