

DE	ET	OE	ES
Document Number: 401677611			
Date Received:			

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10261 Contact Name: KEVIN KANE
 Name of Operator: BAYSWATER EXPLORATION & PRODUCTION LLC Phone: (303) 893-2503
 Address: 730 17TH ST STE 500 Fax: _____
 City: DENVER State: CO Zip: 80202 Email: kkane@bayswater.us

For "Intent" 24 hour notice required, Name: Precup, Jim Tel: (303) 726-3822
COGCC contact: Email: james.precup@state.co.us

API Number 05-001-06420-00 Well Number: 1A
 Well Name: DUMLER
 Location: QtrQtr: SESE Section: 24 Township: 2S Range: 62W Meridian: 6
 County: ADAMS Federal, Indian or State Lease Number: _____
 Field Name: IRONDALE Field Number: 39350

Notice of Intent to Abandon Subsequent Report of Abandonment

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.856711 Longitude: -104.265762
 GPS Data:
 Date of Measurement: 06/14/2012 PDOP Reading: 1.9 GPS Instrument Operator's Name: David Macdonald
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
D SAND	7075	7098			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	226	175	226	0	VISU
1ST	7+7/8	4+1/2	17	7,224	150	7,224	6,200	CALC
	7+7/8	4+1/2	Stage Tool	1,100	160	1,100	0	VISU

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7055 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 50 sks cmt from 426 ft. to 0 ft. Plug Type: ANNULUS Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:

Perforate and squeeze at 6050 ft. with 50 sacks. Leave at least 100 ft. in casing 6000 CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Plugging Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 Yes No *ATTACH JOB SUMMARY

Technical Detail/Comments:

Proposed Plugging Procedure:

- 1) Perform Bradenhead test. Sample any fluid or gas present on bradenhead and provide to the state.
- 2) MIRU workover rig, pump and tank
- 3) Kill well as necessary with treated water
- 4) Unhang rods, unseat pump, POOH LD pump & rods
- 5) NDWH, NUBOPE
- 6) Un-land 2 7/8" production tubing, POOH w/TBG
- 7) RUWL, Run gyro survey
- 8) Run cement bond log, report cement top to engineer
- 9) RIH with CIBP & set @ 7,055', Dump Bail 2 sacks of cement on plug
- 10) RIH & perforate 3 jsp @ 6,050'-6,052', (TOC est = 6,200'). RDWL.
- 11) PU CICR & RIH on 2 7/8" tbg. Set CICR @ 6,000'
- 12) RU Cementers and squeeze perforations with 50 sx cement. Displace cement out retainer, sting out of CICR & dump 2 sx cmt on top of CICR.
- 13) POOH LD TBG.
- 14) RIH with 2 7/8" tubing to 426' (200' below surface casing shoe)
- 15) RU cementers
- 16) Pump cement plug from 426' to surface (estimated @ 50 sx).
- 17) Tag up on cement or confirm to surface
- 18) RDMO location with workover rig
- 19) Dig up and cut casing below surface (6'), weld on dry hole marker
- 20) Remove all surface facilities related to the Dumler 1A.
- 21) Restore Pad as per state requirements.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: PAUL GOTTLOB

Title: Regulatory & Engin. Tech.

Date: _____

Email: paul.gottlob@iptenergyservices.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

COA Type

Description

--	--

Attachment Check List

Att Doc Num

Name

401679315	WELLBORE DIAGRAM
401679316	PROPOSED PLUGGING PROCEDURE
401679317	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

User Group

Comment

Comment Date

		Stamp Upon Approval
--	--	---------------------

Total: 0 comment(s)