



SRC ENERGY

Reviewed: 7/11/19 CD

**Operator:** SRC Energy  
**Well Name:** Weber K 16-23  
**Legal:** SWSE 16 4N 66W  
**Location:** Weld County, CO  
**API:** 05-123-29638  
**Surface:** 8.625" 24# @ 575' MD      **Hole Size:** 12.25"      **TOC:** Surface  
**Production:** 4.5" 11.6# @ 7401' MD      **Hole Size:** 8.625"      **TOC:** 1460' (CBL)  
**Perforations:** 6957'-7130' (Niobrara), 7253'-7268' (Codell)  
**TD:** 7404' MD

P&R Procedure

1. Conduct pre-job safety meeting and complete daily JSA
2. Blow down well if necessary, circulate hole with treated water
3. Dig out around wellhead and perform bradenhead test
4. MIRU WO unit, ND wellhead, NU BOP, tally all pipe
5. TIH w/ 4-1/2" 11.6# CIBP, set at 6,882' MD.
6. Set 16 sxs on top of CIBP (249' above Niobrara)
7. Set 85 sx balanced plug @ 5077' (Shannon and Sussex coverage)
8. Set 23 sx balanced plug @ 2500' (300' plug)
9. Cut 4.5" casing @ 826' MD, and POOH
10. TIH to 868' and pump stub plug (0' – 868')
  - a. 268 sx of 15.8# class G neat 1.15 cu./ft. yield cement
  - b. 293' below surface casing
  - c. trip out of surface casing
  - d. Wait 4 hours and tag plug
11. RDMO WO unit
12. Dig up wellhead and cut off 10' below restored ground level, top off if necessary
13. Weld on cap with ID plate, inscribed with well location, and identity
14. Backfill, clean location
15. P&R complete