

STATE OF COLORADO
OIL AND GAS CONSERVATION COMMISSION
DEPARTMENT OF NATURAL RESOURCES

SUBMIT ORIGINAL AND 1 COPY



00264792

MAY - 5 1997



FOR OFFICE USE ONLY			
ET	FE	UC	SE

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> COALBED METHANE <input type="checkbox"/> INJECTION WELL <input type="checkbox"/> OTHER			5. FEDERAL, INDIAN OR STATE LEASE NO.
2. NAME OF OPERATOR Kenisa Oil Company			6. PERMIT NO. 93-354
3. ADDRESS OF OPERATOR 518 17th St., Suite 1180 CITY STATE ZIP CODE Denver CO 80202			7. API NO. 05-075-09259
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 2175' FNL & 1785' FWL At proposed prod. zone			8. WELL NAME A Horsetail
			9. WELL NUMBER #1
12. COUNTY Logan			10. FIELD OR WILDCAT Cedar Creek North
			11. QTR. QTR. SEC., T.R. AND MERIDIAN SW SE NW Sec. 2, T.9N, R.54W

Check Appropriate Box To Indicate Nature of Notice, Report or Notification

13A. NOTICE OF INTENTION TO:

- ☒ PLUG AND ABANDON
☐ MULTIPLE COMPLETION
☐ COMMINGLE ZONES
☐ FRACTURE TREAT
☐ REPAIR WELL
☐ OTHER

13B. SUBSEQUENT REPORT OF:

- ☐ FINAL PLUG AND ABANDONMENT
(SUBMIT 3RD PARTY CEMENT VERIFICATION
AND JOB LOG)
☐ ABANDONED LOCATION (WELL NEVER DRILLED-
SITE MUST BE RESTORED WITHIN 6 MONTHS)
☐ REPAIRED WELL
☐ OTHER

*Use Form 5 - Well Completion or Recompletion Report and Log
for subsequent report of Multiple/Commungled Completions
and Recompletions

13C. NOTIFICATION OF:

- ☐ SHUT-IN, TEMPORARILY ABANDONED
(DATE _____)
(REQUIRED EVERY 6 MONTHS)
☐ PRODUCTION RESUMED
(DATE _____)
☐ LOCATION CHANGE (SUBMIT NEW PLAT)
☐ WELL NAME CHANGE
☐ OTHER

14. DESCRIBE PROPOSED OR COMPLETED OPERATIONS ON THIS FORM (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent)

15. DATE OF WORK

1. Pull tubing and load hole w/water.
2. Set CIBP @ 4960' ± on wireline.
3. Set 2 sx cement on top of CIBP w/wireline dump bailer.
4. Pull stretch in 4 1/2" casing and cut off 4 1/2" above free point.
5. Lay down 4 1/2" casing. 40'
6. Set 40 sx cement plug 20' below base of surface casing @ 186' K.B. 206'
7. Set 10 sx cement plug at surface.
8. Cut off 8 5/8" surface casing 4' below surface.
9. Weld metal plate on top of surface casing.
10. Level and restore surface of wellsite.

16. I hereby certify that the foregoing is true and correct

SIGNED Robert W. Peterson TELEPHONE NO. (303) 861-2470NAME (PRINT) Robert W. Peterson TITLE Petroleum Engineer DATE 5/2/97

(This space for Federal or State office use)

APPROVED D. K. DILCON SR. PETROLEUM ENGINEER
CONDITIONS OF APPROVAL, IF ANY: TITLE O & G Cons Comm DATE MAY 05 1997