

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

USA, Colo. 14545

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. UNIT AGREEMENT NAME
2. NAME OF OPERATOR Trend Exploration Ltd.		8. FARM OR LEASE NAME Federal 1-35
3. ADDRESS OF OPERATOR 600 Capitol Life Center, Denver, Colorado 80203		9. WELL NO. 1-35
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2200' FEL & 2100' FSL Sec. 35-T7N-R81W		10. FIELD AND POOL, OR WILDCAT Coalmont
14. PERMIT NO. 72918		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA NW 1/4 SE 1/4 Sec. 35 T7N R81W
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 8288KB		12. COUNTY OR PARISH Jackson
		13. STATE Colo.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

SUBSEQUENT REPORT OF:

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers pertinent to this work.)*

If well does not respond to frac. treatment, we propose to plug and abandon as follows:

1. Pull and lay down 1 1/4" tbg., pull 2-3/8" tbg. and stand back in derrick
2. Set cement retainer @ 6050'
3. Circulate oil out of hole w/ 9.5# mud
4. Squeeze perms 6169-6619 w/ 150 sx cement
5. Pressure test CR and casing to 1000 psi
6. Locate free point and cut 5 1/2" csg. pull and lay down (approx. 5100')
7. Spot cement plug across 5 1/2" csg stub (25' in csg. and 125' on top)
8. Spot 150' cement plug 2300-2450'
9. Spot 100' cement plug @ bottom of 10-3/4" csg (350-450')
10. Spot 10 sx cement plug @ surface, cut off csg. below plow depth and install regulation abandonment marker
11. Clean and restore drilling site.

DVR	
FJP	✓
HHM	✓
JAM	✓
JJD	✓
GCH	✓
CCM	✓

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Production Supervisor

DATE June 10, 1976

(This space for Federal or State office use)

DIRECTOR

D & B CONS. COMM.

APPROVED BY

TITLE

DATE JUN 28 1976

CONDITIONS OF APPROVAL, IF ANY: