

Document Number:
 402306569
 Date Received:
 02/12/2020

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10112 Contact Name: Wes Wickersham
 Name of Operator: FOUNDATION ENERGY MANAGEMENT LLC Phone: (918) 5262236
 Address: 5057 KELLER SPRINGS RD STE 650 Fax: _____
 City: ADDISON State: TX Zip: 75001 Email: wwickersham@foundationenergy.com
For "Intent" 24 hour notice required, Name: Welsh, Brian Tel: (719) 325-6919
COGCC contact: Email: brian.welsh@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-125-06103-00
 Well Name: ALLISON Well Number: 1-32
 Location: QtrQtr: SWNE Section: 32 Township: 1S Range: 44W Meridian: 6
 County: YUMA Federal, Indian or State Lease Number: _____
 Field Name: VERNON Field Number: 86500

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.928160 Longitude: -102.323841
 GPS Data: GPS Quality Value: 2.8 Type of GPS Quality Value: PDOP Date of Measurement: 03/31/2007
 GPS Instrument Operator's Name: Kevin McCormick
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other _____
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	2096	2116			
Total: 1 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	9+7/8	7	20	220	95	220	0	VISU
1ST	6+1/4	4+1/2	10.5	2,219	80	2,219	1,400	CALC

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 2050 with 2 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 45 sks cmt from 440 ft. to 0 ft. Plug Type: CASING Plug Tagged:
Set 10 sks cmt from 1500 ft. to 1400 ft. Plug Type: CASING Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
Perforate and squeeze at 440 ft. with 45 sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
Set _____ sacks at surface
Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Cut and Cap Date: _____
of _____
*Wireline Contractor: _____ *Cementing Contractor: _____
Type of Cement and Additives Used: _____
Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Alyssa Beard
Title: HSE Regulatory Manager Date: 2/12/2020 Email: ABeard@foundationenergy.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 3/16/2020

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: 9/15/2020

COA Type	Description
	<p>Venting Operator shall implement measures to control unnecessary and excessive venting, to protect the health and safety of the public, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.</p>
	<p>Plugging 1) Provide 48 hour notice of plugging MIRU via electronic Form 42. 2) Properly abandon flowlines as per Rule 1105. File electronic Form 42 once abandonment complete. Within 30 days of an operator completing abandonment requirements for an off-location flowline or crude oil transfer line the operator must submit a Flowline Report, Form 44. 3) Plugs and squeezes will be placed as stated in the Plugging Procedure section of the approved NOIA unless revised by COA or prior approval from COGCC is obtained. 4) The wellbore must be static prior to placing cement plugs which are to be a minimum of 100' in length for all but surface plugs. Mechanical isolation requires a 25' cement plug, minimum. 5) Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. Confirm cement to surface in all strings during cut and cap. 6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed. 7) Contact area inspector prior to commencing plugging operations. 8) No current Form 17 on file with COGCC. Contact COGCC area engineer with results of pre-plugging bradenhead test for confirmation of plugging procedure prior to commencing plugging operations. 9) After placing the shallowest hydrocarbon isolating plug (2050'), operator must wait a sufficient time on all subsequent plugs to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC engineering before continuing operations. 10) Add a 10 sks cement casing plug at 1500-1400'. WOC 4 hrs in order to assure that there is no pressure or flow before proceeding with plugging procedure, additional plugs may be necessary to shut off pressure or flow prior to isolating the surface shoe. Contact COGCC Area Engineer if well is not static prior to placing any subsequent plugs. 11) Assure that wellbore is static and pump 90 sx combined shoe/surface plug from 440 -0'. Tag required if cement does not circulates to surface and stay there. 12) This well must be Plugged and Abandoned or successfully pass a Mechanical Integrity Test by 6/30/2020.</p>
	<p>Bradenhead Testing Prior to starting plugging operations a bradenhead test shall be performed if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations. 1) If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required. 2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required.</p> <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.</p> <p>If there is a need for sampling, contact COGCC engineering for verification of plugging procedure.</p>

Attachment Check List

<u>Att Doc Num</u>	<u>Name</u>
402306569	FORM 6 INTENT SUBMITTED
402309582	WELLBORE DIAGRAM
402309583	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	WW + Elev + 50 = 390 + 3906 - 3940 + 50 = 406' Logs1/15/1977 385' L-FH base, 1200' UPA base	03/16/2020

Total: 1 comment(s)