

FORM
6Rev
02/20

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

402402719

Date Received:

05/21/2020

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10110	Contact Name: Kapri McMillan
Name of Operator: GREAT WESTERN OPERATING COMPANY LLC	Phone: (970) 364-2826
Address: 1001 17TH STREET #2000	Fax:
City: DENVER State: CO Zip: 80202	Email: kmcmillan@gwp.com
For "Intent" 24 hour notice required, Name: Santistevan, Brittani Tel: (720) 471-1110 Email: brittani.santistevan@state.co.us COGCC contact:	

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number: 05-123-24315-00	Well Name: GREAT WESTERN	Well Number: 27-24
Location: QtrQtr: SWSW Section: 27 Township: 6N Range: 67W Meridian: 6		
County: WELD	Federal, Indian or State Lease Number:	
Field Name: WATTENBERG	Field Number: 90750	

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.453510	Longitude: -104.887820
GPS Data: GPS Quality Value: 2.1 Type of GPS Quality Value:	Date of Measurement: 09/24/2007
GPS Instrument Operator's Name: TJ DEGUERO, TST,	
Reason for Abandonment: <input type="checkbox"/> Dry <input checked="" type="checkbox"/> Production Sub-economic <input type="checkbox"/> Mechanical Problems	
<input type="checkbox"/> Other	
Casing to be pulled: <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	Estimated Depth: 2500
Fish in Hole: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	If yes, explain details below
Wellbore has Uncemented Casing leaks: <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	If yes, explain details below
Details:	

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
CODELL	7304	7324			
NIOBRARA	7028	7198			
Total: 2 zone(s)					

Casing History

Casing Type	Size of Hole	Size of Casing	Weight Per Foot	Setting Depth	Sacks Cement	Cement Bot	Cement Top	Status
SURF	12+1/4	8+5/8	24	444	380	444	0	CALC
1ST	7+7/8	4+1/2	11.6	7,467	160	7,467	6,444	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 6980 with 25 sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 10 sks cmt from 4200 ft. to 4070 ft. Plug Type: CASING Plug Tagged: ☐
Set 45 sks cmt from 2550 ft. to 2300 ft. Plug Type: STUB PLUG Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 4300 ft. with 50 sacks. Leave at least 100 ft. in casing 4200 CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 375 sacks half in. half out surface casing from 1200 ft. to 0 ft. Plug Tagged: ☒

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. _____ inch casing Cut and Cap Date: _____
of _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

Procedure:

- 1 Contact COGCC
- 2 MIRU
- 3 Blow down and kill well
- 4 NDWH/NUBOP
- 5 Roll hole clean
- 6 Set CIBP @ 6980'
- 7 Pump 25 sx Thermal 35 on top of plug @ 6980'
- 8 TOOH w/ tubing, stand back
- 9 RIH w/ WL and shoot holes at 4300' and 4100'
- 10 RIH and set CICR @ 4200'
- 11 Squeeze 50 sx thru CICR, leave additional 10 sx on top Class G
- 12 Roll hole clean
- 13 Release flowback if no longer needed
- 14 Cut & pull casing @ 2500'
- 15 Pump stub plug from 2550' w/ 45 sx AGM (1.86ft3/sx) (est TOC @ 2300')
- 16 WOC 4 hours, tag plug, check for migration
- 17 PU to 1200' and pump 375 sx Class G to surface
- 18 WOC 4 hours
- 19 RIH tag, top off w/ cement as needed
- 20 RDMO
- 21 Cut & cap casing 4' - 6' below GL w/ plate (Well Name, API, Legal Location)

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Renee Kendrick
 Title: SR Regulatory Analyst Date: 5/21/2020 Email: rkendrick@gwp.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: JENKINS, STEVE Date: 6/2/2020

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 12/1/2020

COA Type	Description
	<p>For Wells with known Bradenhead pressures:</p> <ol style="list-style-type: none"> 1) Provide 48-hour notice of plugging MIRU via electronic Form 42. 2) The plug at 2550' needs to be placed and have an 8-hour WOC to assure that all fluid migration has been stopped. If that doesn't isolate the flow, additional attempts in front of the surface shoe plug will need to be attempted. Other downhole potential squeeze opportunities may need to be looked at before the 1200' plug. 3) Prior to placing the 1200' plug: verify that all fluid migration (liquid or gas) has been eliminated. If evidence of fluid migration or pressure remains, contact COGCC Engineer for an update to plugging orders. 4) After isolation has been verified, pump plug and displace. If cement is not circulated to surface, shut-in, WOC 4 hours then tag plug – must be at 394' or shallower and provide 10 sx plug at the surface. Leave at least 100' of cement in the casing for each plug. 5) Properly abandon flowlines as per Rule 1105. File electronic Form 42 once abandonment is complete. Within 30 days of an operator completing abandonment requirements for an off-location flowline or crude oil transfer line, the operator must submit a Flowline Report, Form 44. 6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed. 7) After placing the shallowest hydrocarbon isolating plug (2550'), operator must wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC engineering before continuing operations.
	Operator shall implement measures to control venting, to protect health and safety, and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare.
	<p>Prior to starting plugging operations a Bradenhead test shall be performed if there has not been a reported Bradenhead test within the 60 days immediately preceding the start of plugging operations.</p> <ol style="list-style-type: none"> 1) If, before opening the Bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required. 2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required. <p>The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.</p>

Attachment Check List

Att Doc Num	Name
402402719	FORM 6 INTENT SUBMITTED
402402897	WELLBORE DIAGRAM
402403580	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	1) Deepest Water Well within 1 mile = 300'. 2) Fox Hills Bottom- N/A, per SB5.	06/02/2020
Engineer	In accordance with the Notice to Operators (NTO): Timing for COGCC Forms adopted on 05/01/2020, this Form 6 Notice of Intent to Abandon is valid for 12 months from the date of approval expiring on 06/02/2021. This NTO does not alter the deadlines for submission of, or compliance with any other Commission rule or Form.	06/02/2020
Permit	•Permitting review complete and task passed.	06/01/2020
Permit	•Returned to draft at Operator's request.	05/20/2020

Total: 4 comment(s)