

A28 SVE

Date	Well	Start Time	Start PID	Stop Time	Stop PID	SCFM	Vacuum
3/11/2020	SVENW01	2:10:00 PM	0.1	2:40:00 PM	0.0	85	NA
	SVEMID01	2:45:00 PM	0.0	3:15:00 PM	0.1	85	NA
3/12/2020	SVESW01	9:05:00 AM	0.2	9:35:00 AM	1.4	90	NA
	SVE01	9:40:00 AM	0.2	10:10:00 AM	0.0	80	NA
	SVE08	10:15:00 AM	0.1	10:45:00 AM	0.0	80	NA
	SVE09	11:00:00 AM	3.7	11:30:00 AM	7.7	70	NA
	SVESE01	11:00:00 AM	3.7	11:30:00 AM	7.7	70	NA
	SVEN01	11:35:00 AM	3.3	11:55:00 AM	1.5	70	NA
	SVENE01	12:00:00 PM	0.9	12:30:00 PM	1.3	70	NA
Date	Well	Start Time	Start PID	Stop Time	Stop PID	SCFM	Vacuum
5/13/2020	SVENW01	2:10:00 PM	0.3	2:40:00 PM	1.3	80	NA
5/14/2020	SVEMID01	9:50:00 AM	0.6	10:20:00 AM	0.3	80	NA
	SVESW01	10:30:00 AM	0.1	11:00:00 AM	0.6	80	NA
	SVE01	11:50:00 AM	13.5	12:20:00 PM	21.6	80	NA
	SVE08	11:10:00 AM	6.3	11:40:00 AM	12.7	80	NA
	SVE09	12:30:00 PM	12.9	1:00:00 PM	16.4	80	NA
	SVESE01	1:45:00 PM	1.4	2:15:00 PM	1.0	80	NA
	SVEN01	1:05:00 PM	0.1	1:35:00 PM	1.3	80	NA
	SVENE01	1:45:00 PM	1.4	2:15:00 PM	1.0	80	NA
Date	Well	Start Time	Start PID	Stop Time	Stop PID	SCFM	Vacuum
8/25/2020	SVENW01	1:20:00 PM	0.3	1:50:00 PM	0.4	120	NA
8/26/2020	SVEMID01	7:35:00 AM	6.1	8:05:00 AM	4.0	120	NA
	SVESW01	8:10:00 AM	1.0	8:40:00 AM	3.0	120	NA
	SVE01	9:25:00 AM	51.2	9:55:00 AM	39.7	80	NA
	SVE08	10:00:00 AM	19.0	10:30:00 AM	28.9	90	NA
	SVE09	10:35:00 AM	26.3	10:55:00 AM	29.7	90	NA
	SVESE01	11:20:00 AM	1.8	11:50:00 AM	3.4	130	NA
	SVEN01	8:50:00 AM	2.1	9:20:00 AM	1.1	120	NA
	SVENE01	11:20:00 AM	1.8	11:50:00 AM	3.4	130	NA
Date	Well	Start Time	Start PID	Stop Time	Stop PID	SCFM	Vacuum
10/28/2020	SVENW01	2:10:00 PM	1.3	2:40:00 PM	3.7	130	NA
10/29/2020	SVEMID01	8:40:00 AM	6.0	9:10:00 AM	5.0	130	NA
	SVESW01	9:20:00 AM	1.3	9:50:00 AM	3.7	130	NA
	SVE01	10:35:00 AM	19.3	10:55:00 AM	23.5	100	NA
	SVE08	10:00:00 AM	13.4	10:30:00 AM	19.8	110	NA
	SVE09	11:00:00 AM	17.9	11:30:00 AM	21.0	100	NA
	SVESE01	12:15:00 AM	1.3	12:45:00 AM	4.8	140	NA
	SVEN01	11:35:00 AM	5.7	11:55:00 AM	1.7	130	NA
	SVENE01	12:15:00 AM	1.3	12:45:00 AM	4.8	140	NA