

Document Number:
 402628402
 Date Received:
 03/15/2021

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set. A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 99999 Contact Name: Shannon Chollett
 Name of Operator: OLD OPERATORS - STATUS UNKNOWN Phone: (970) 250-0130
 Address: SEE COMMENT LINE IN WELL Fax: _____
 City: XXXXXXX State: XX Zip: _____ Email: shannon.chollett@state.co.us

For "Intent" 24 hour notice required, Name: Labowskie, Steve Tel: (970) 946-5073
COGCC contact: Email: steve.labowskie@state.co.us

Type of Well Abandonment Report: Notice of Intent to Abandon Subsequent Report of Abandonment

API Number 05-007-40033-00
 Well Name: Underwood Ditch (OWP) Well Number: 1
 Location: QtrQtr: SENE Section: 4 Township: 32N Range: 1E Meridian: N
 County: ARCHULETA Federal, Indian or State Lease Number: _____
 Field Name: WILDCAT Field Number: 99999

Only Complete the Following Background Information for Intent to Abandon

Latitude: 37.043990 Longitude: -106.840660
 GPS Data: GPS Quality Value: _____ Type of GPS Quality Value: _____ Date of Measurement: _____
 Reason for Abandonment: Dry Production Sub-economic Mechanical Problems
 Other OWP Well
 Casing to be pulled: Yes No Estimated Depth: _____
 Fish in Hole: Yes No If yes, explain details below
 Wellbore has Uncemented Casing leaks: Yes No If yes, explain details below
 Details: _____

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth

Total: 0 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	10+1/2	8+5/8	NA	NA	0	0			0	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth _____ with _____ sacks cmt on top. CIBP #2: Depth _____ with _____ sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged:
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
(Cast Iron Cement Retainer Depth)
 Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged:
 Set _____ sacks at surface
 Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: Yes No
 Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
 Surface Plug Setting Date: _____ Cut and Cap Date: _____
 *Wireline Contractor: _____ *Cementing Contractor: _____
 Type of Cement and Additives Used: _____
 Flowline/Pipeline has been abandoned per Rule 1105 Yes No

Technical Detail/Comments:

No records on file. This well will be plugged according to COGCC rules and guidelines once more information is gathered during the commencement of onsite field work.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Shannon Chollett
 Title: OWP Engineer Date: 3/15/2021 Email: shannon.chollett@state.co.us

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Duran, Alicia Date: 3/29/2021

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: 9/28/2021

COA Type	Description
	If water is present around the wellhead and surrounding area during plugging and abandonment operations, operator will implement measures to drain the water and stabilized the area around the wellhead to support the workover rig and prevent any off location migration of sediment to any nearby surface water feature. If site drainage and stabilization cannot be accomplished, plugging and abandonment of this well should be conducted during the low flow / winter season (December to February).

1) Provide 48 hour notice of plugging MIRU via electronic Form 42.

2) Operator shall implement measures to control unnecessary and excessive venting and to ensure that vapors and odors from well plugging operations do not constitute a nuisance or hazard to public welfare, health and safety.

3) Properly abandon flowlines as per Rule 1105. Attach flowline abandonment job summary detailing compliance with Rule 1105.c when filing Form 6 (s). File electronic Form 42 once abandonment complete. Within 30 days of an operator completing abandonment requirements for an off-location flowline or crude oil transfer line the operator shall submit a Flowline Report, Form 44.

4) Prior to killing the well, measure the surface casing pressure (Braden Head) and perform a Braden Head test. Report results on a Form 17. If pressure is greater than 25 psi contact COGCC area engineer.

a. A sample of both the production and bradenhead gas shall be collected and submitted for laboratory analysis of the gas composition and stable isotopes. (only if there is no CICR, Bridge plug etc. downhole. If there is CICR then only Bradenhead) The compositional analysis should include hydrogen, argon, oxygen, carbon dioxide, nitrogen, methane (C1), ethane (C2), ethene, propane (nC3), isobutane (iC4), butane (nC4), isopentane (iC5), pentane (nC5), hexanes +, specific gravity and British Thermal Units (BTU). The stable isotope analysis should include delta DC1, delta 13C1, delta 13C2, delta 13C3, delta 13iC4, delta 13nC4, delta 13iC5 (if possible), delta 13nC5 (if possible), and delta 13C of CO2 (if possible). The analytical results shall be submitted to the COGCC via Form 43 (Analytical Sample Submittal Form).

b. Gas sample containers should be filled in accordance with container manufacturer or laboratory recommendations; purging multiple container volumes may not be feasible due to limited gas volumes.

c. If water is encountered in the bradenhead during testing then samples should be collected and submitted for the laboratory analysis of major anions (chloride, carbonate, bicarbonate, and sulfate), cations (sodium, potassium, calcium, and magnesium) total dissolved solids (TDS), BTEX, DRO, GRO, and dissolved gasses (RSK 175). If there is a limited amount of water available then anions, cations and BTEX should be given first priority. Data from bradenhead water samples shall be submitted to the COGCC via Form 43.

d. Please refer to Appendix A of the COGCC Operator Instructions for Bradenhead Testing and Reporting for more information regarding testing and sampling protocol.

e. The operator shall provide notice to Environmental Supervisor Alex Fischer at alex.fischer@state.co.us or 303-894-2100 X 5138 and Southwest Region Engineer Alicia Duran at alicia.duran@state.co.us or 303-548-7396, a minimum of 72 hours prior to conducting field operations. Bradenhead testing and sample collection (if applicable). If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.

f. Continue to monitor the surface casing pressure throughout the PA

g. Check for gas venting outside the surface casing (use gas monitor or flood the cellar with water and look for bubbles)

5) Pressure test casing.

6) Do not install surface casing shoe plug unless the surface casing pressure is zero. If there is pressure, additional deeper plug(s) will be required to ensure no surface casing pressure.

PA marker

7) Discuss the type of PA marker with the landowner (welded plate or post)

8) The PA marker shall be inscribed with the well's legal location, well name and number, and API Number.

9) Leave a vent hole in casing/marker to avoid trapping any potential residual pressure in the casing(s)

Submit "as drilled" GPS data on Subsequent Report of Abandonment. GPS data must meet the requirements of Rule 215.

Attachment List

<u>Att Doc Num</u>	<u>Name</u>
402628402	WELL ABANDONMENT REPORT (INTENT)
402628411	WELLBORE DIAGRAM
402641477	FORM 6 INTENT SUBMITTED

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Permit	Cannot confirm as-drilled well location. No other forms in process. Production reporting OK. No records on file. Reviewed WBD. Pass.	03/16/2021

Total: 1 comment(s)