

FORM
6Rev
11/20

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402914589

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Valerie Danson

Name of Operator: PDC ENERGY INC

Phone: (970) 506-9272

Address: 1775 SHERMAN STREET - STE 3000

Fax:

City: DENVER

State: CO

Zip: 80203

Email: valerie.danson@pdce.com

For "Intent" 24 hour notice required,

Name: Santistevan, Brittani

Tel: (720) 471-1110

COGCC contact:

Email: brittani.santistevan@state.co.us

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number 05-123-30113-00

Well Name: LUNDVALL J

Well Number: 18-01D

Location: QtrQtr: SWNE

Section: 18

Township: 5N

Range: 66W

Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.400989

Longitude: -104.819937

GPS Data: GPS Quality Value: 2.7 Type of GPS Quality Value: Date of Measurement: 07/14/2009

Reason for Abandonment: ☐ Dry ☒ Production Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

Current and Previously Abandoned Zones

| Formation | Perf. Top | Perf. Btm | Abandoned Date | Method of Isolation | Plug Depth |
|-----------------|-----------|-----------|----------------|---------------------|------------|
| NIOBRARA-CODELL | 7574 | 7781 | | | |

Total: 1 zone(s)

Casing History

| Casing Type | Size of Hole | Size of Casing | Grade | Wt/Ft | Csg/Liner Top | Setting Depth | Sacks Cmt | Cmt Btm | Cmt Top | Status |
|-------------|--------------|----------------|-------|-------|---------------|---------------|-----------|---------|---------|--------|
| SURF | 12+1/4 | 8+5/8 | J55 | 24 | 0 | 573 | 249 | 573 | 0 | VISU |
| 1ST | 7+7/8 | 4+1/2 | J55 | 11.6 | 0 | 7921 | 1000 | 7921 | 402 | CBL |

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7524 with 2 sacks cmt on top. CIBP #2: Depth 2500 with 2 sacks cmt on top.
 CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
 CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

| | | |
|---|------------------|---------------------------------------|
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |
| Set _____ sks cmt from _____ ft. to _____ ft. | Plug Type: _____ | Plug Tagged: <input type="checkbox"/> |

Perforate and squeeze at 380 ft. with 76 sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
 Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 122 sacks half in. half out surface casing from 1620 ft. to 0 ft. Plug Tagged: ☒

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____
 Surface Plug Setting Date: _____ Cut and Cap Date: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

Lundvall J 18-01D (05-123-30113) / Plugging Procedure (Intent)
 Producing Formations: Niobrara/Codell: 7574'-7781'

Upper Pierre Aquifer: 540'-1520'

Deepest Water Well: 100'
 TD: 7930' PBTD: 7862' (5/7/2010)
 Surface Casing: 8 5/8" 24# @ 573' w/ 249 sxs cmt
 Production Casing: 4 1/2" 11.6# @ 7921' w/ 1000 sxs (TOC @ 402' – CBL)

Tubing: 2 3/8" tubing @ 7741' (5/10/2010)

Proposed Procedure:

1. MIRU pulling unit. Pull 2 3/8" tubing.
2. RU wireline company.
3. TIH with CIBP. Set BP at 7524'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Nio perms @ 7574')
4. TIH with CIBP. Set BP at 2500'. Top with 2 sxs 15.8#/gal CI G cement.
5. Wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or fluid migration, contact engineering before continuing operations.
6. Unland casing and perform stretch calculation confirming surface squeeze can be executed. Adjust squeeze holes and cement as necessary.
7. TIH with perf gun. Shoot squeeze holes @ 380'.
8. TIH with tubing to 1620'. RU cementing company. Mix and pump 122 sxs 15.8#/gal CI G cement down tubing. (Pierre Coverage from 1620' to Surface) Cement should circulate to surface.
9. Close off casing returns. Hook up cement line to cement flange and pump 76 sxs 15.8#/gal CI G cement downhole and squeeze through perms at 380' into annular space. Cement should circulate to surface.
10. Well casing cut and capped per COGCC guidelines at a depth as not to interfere with soil cultivation.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____

Print Name: Valerie Danson

Title: Reg Analyst

Date: _____

Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____

Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____

Expiration Date: _____

COA Type

Description

| | |
|--|--|
| | |
|--|--|

Attachment List

Att Doc Num

Name

| | |
|-----------|------------------|
| 402914626 | WELLBORE DIAGRAM |
| 402914628 | WELLBORE DIAGRAM |

Total Attach: 2 Files

General Comments

User Group

Comment

Comment Date

| | | |
|--|--|---------------------|
| | | Stamp Upon Approval |
|--|--|---------------------|

Total: 0 comment(s)