

FORM
6Rev
11/20

State of Colorado

Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE ET OE ES

Document Number:

402935518

Date Received:

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 69175

Contact Name: Valerie Danson

Name of Operator: PDC ENERGY INC

Phone: (970) 506-9272

Address: 1775 SHERMAN STREET - STE 3000

Fax:

City: DENVER State: CO Zip: 80203

Email: valerie.danson@pdce.com

For "Intent" 24 hour notice required,

Name: Burns, Adam

Tel: (970) 218-4885

COGCC contact:

Email: adam.m.burns@state.co.us

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number 05-123-26269-00

Well Name: GUTTERSEN

Well Number: 44-12

Location: QtrQtr: SESE Section: 12 Township: 3N Range: 64W Meridian: 6

County: WELD

Federal, Indian or State Lease Number:

Field Name: WATTENBERG

Field Number: 90750

Only Complete the Following Background Information for Intent to Abandon

Latitude: 40.234390

Longitude: -104.492500

GPS Data: GPS Quality Value: 2.2 Type of GPS Quality Value: Date of Measurement: 01/18/2008

Reason for Abandonment: ☐ Dry ☒ Production Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☒ Yes ☐ No Estimated Depth: 2500Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA-CODELL	6580	6809			
J SAND	7264	7270	06/04/2008	B PLUG CEMENT TOP	7000

Total: 2 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	12+1/4	8+5/8	J55	24	0	675	380	675	0	VISU
1ST	7+7/8	4+1/2	J55	10.5	0	7426	220	7426	6070	CBL
S.C. 1.1						4815	315	4815	3250	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 7214 with 2 sacks cmt on top. CIBP #2: Depth 6530 with 2 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set 100 sks cmt from 2550 ft. to 2300 ft. Plug Type: STUB PLUG Plug Tagged: ☐
Set 100 sks cmt from 1635 ft. to 1435 ft. Plug Type: OPEN HOLE Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth
Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set 393 sacks half in. half out surface casing from 875 ft. to 0 ft. Plug Tagged: ☒

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing

Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____

*Wireline Contractor: _____ *Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

Guttersen 44-12 (05-123-26269) / Plugging Procedure (Intent)
 Producing Formations: Niobrara/Codell: 6580'-6809'
 Abandoned Formation: J-Sand: 7264'-7270'
 Upper Pierre Aquifer: 655'-1535'
 Deepest Water Well: 270' Base of Fox Hills: 491'
 TD: 7431' PBTD: 7389' (3/6/2008)
 Surface Casing: 8 5/8" 24# @ 675' w/ 380 sxs cmt
 Production Casing: 4 1/2" 10.5# @ 7426' w/ 220 sxs (TOC @ 6070' – CBL)
 S.C.C.1. @ 4815' w/ 315 sxs (TOC @ 3250' – CBL)
 Existing CIBP @ 7000' w/ 2 sxs cmt (6/4/2008)

Tubing: 2 3/8" tubing @ 6790' (8/6/2008)

Proposed Procedure:

1. MIRU pulling unit. Pull 2 3/8" tubing.
2. RIH w/ 3-7/8" bit and workstring. Establish circulation. Drill out CIBP @ 7000' and cleanout to top of J-Sand @ 7264'. Circulate well clean. LD bit & workstring.
3. RU wireline company.
4. TIH with CIBP. Set BP at 7214'. Top with 2 sxs 15.8#/gal CI G cement. (Top of J-Sand perfs @ 7264')
5. TIH with CIBP. Set BP at 6530'. Top with 2 sxs 15.8#/gal CI G cement. (Top of Nio perfs @ 6580')
6. TIH with casing cutter. Cut 4 1/2" casing @ 2500'. Pull cut casing.
7. TIH with tubing to 2550'. RU cementing company. Mix and pump 100 sxs 15.8#/gal CI G cement down tubing. (Stub Plug from 2550'-2300')
8. Wait a sufficient time to confirm static conditions. If at any time after placing this plug there is evidence of pressure or fluid migration, contact engineering before continuing operations.
9. TIH with tubing to 1635'. Mix and pump 100 sxs 15.8#/gal CI G cement down tubing. (Pierre Coverage from 1635'-1435')
10. Pick up with tubing to 875'. Mix and pump 393 sxs 15.8#/gal CI G cement down tubing. Cement should circulate to surface.
11. Well casing cut and capped per COGCC guidelines at a depth as not to interfere with soil cultivation.

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Valerie Danson
 Title: Reg Analyst Date: _____ Email: valerie.danson@pdce.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: _____ Date: _____

CONDITIONS OF APPROVAL, IF ANY: _____ Expiration Date: _____

COA Type	Description

Attachment List

Att Doc Num	Name
402935719	WELLBORE DIAGRAM
402935720	WELLBORE DIAGRAM

Total Attach: 2 Files

General Comments

User Group	Comment	Comment Date
		Stamp Upon Approval

Total: 0 comment(s)