

FORM
6Rev
11/20

State of Colorado Oil and Gas Conservation Commission

1120 Lincoln Street, Suite 801, Denver, Colorado 80203 Phone: (303) 894-2100 Fax: (303) 894-2109



DE	ET	OE	ES
----	----	----	----

Document Number:

403145375

Date Received:

08/24/2022

WELL ABANDONMENT REPORT

This form is to be submitted as an Intent to Abandon whenever an abandonment is planned on a borehole. After the abandonment is complete, this form shall again be submitted as a Subsequent Report of the actual work completed. The approved intent shall be valid for six months after the approval date, after that period, a new intent will be required. Attachments required with the Intent to Abandon are wellbore diagrams of the current configuration and the proposed configuration with plugs set.

A Subsequent Report of Abandonment shall indicate the actual work completed. Attachments required with a Subsequent Report are a wellbore diagram showing plugs that were set and casing remaining in the hole, the job summaries from all plugging contractors used, including wireline and cementing (third party verification) and any logs that may have been run during abandonment.

OGCC Operator Number: 10699

Contact Name: James Krehmeyer

Name of Operator: OWN RESOURCES OPERATING LLC

Phone: (970) 332-3585

Address: 38 PALMER CREST CT

Fax:

City: SPRING State: TX Zip: 77381

Email: james.krehmeyer@ownresources.com

For "Intent" 24 hour notice required,

Name: Welsh, Brian

Tel: (719) 325-6919

COGCC contact:

Email: brian.welsh@state.co.us

Type of Well Abandonment Report: ☒ Notice of Intent to Abandon ☐ Subsequent Report of Abandonment

API Number 05-125-08377-00

Well Name: MOELLENBERG

Well Number: 21-31443

Location: QtrQtr: NENW Section: 31 Township: 4S Range: 43W Meridian: 6

County: YUMA

Federal, Indian or State Lease Number:

Field Name: BONNY

Field Number: 7325

Only Complete the Following Background Information for Intent to Abandon

Latitude: 39.670990

Longitude: -102.225685

GPS Data: GPS Quality Value: 2.1 Type of GPS Quality Value: PDOP Date of Measurement: 09/17/2009

Reason for Abandonment: ☐ Dry ☒ Production Sub-economic ☐ Mechanical Problems☐ OtherCasing to be pulled: ☐ Yes ☒ No Estimated Depth:Fish in Hole: ☐ Yes ☒ No If yes, explain details belowWellbore has Uncemented Casing leaks: ☐ Yes ☒ No If yes, explain details below

Details:

Current and Previously Abandoned Zones

Formation	Perf. Top	Perf. Btm	Abandoned Date	Method of Isolation	Plug Depth
NIOBRARA	1548	1588			

Total: 1 zone(s)

Casing History

Casing Type	Size of Hole	Size of Casing	Grade	Wt/Ft	Csg/Liner Top	Setting Depth	Sacks Cmt	Cmt Btm	Cmt Top	Status
SURF	9+7/8	7	j-55	16	0	308	125	308	0	CALC
1ST	6+1/4	4+1/2	j-55	10.5	0	1793	75	1793	970	CBL

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 1498 with 2 sacks cmt on top. CIBP #2: Depth 1300 with 2 sacks cmt on top.
CIBP #3: Depth _____ with _____ sacks cmt on top. CIBP #4: Depth _____ with _____ sacks cmt on top.
CIBP #5: Depth _____ with _____ sacks cmt on top.

NOTE: Two(2) sacks cement required on all CIBPs.

Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐
Set _____ sks cmt from _____ ft. to _____ ft. Plug Type: _____ Plug Tagged: ☐

Perforate and squeeze at 360 ft. with 110 sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

Perforate and squeeze at _____ ft. with _____ sacks. Leave at least 100 ft. in casing _____ CICR Depth

(Cast Iron Cement Retainer Depth)

Set _____ sacks half in. half out surface casing from _____ ft. to _____ ft. Plug Tagged: ☐

Set _____ sacks at surface

Cut four feet below ground level, weld on plate Above Ground Dry-Hole Marker: ☐ Yes ☐ No

Set _____ sacks in rat hole Set _____ sacks in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing Recovered: _____ ft. of _____ inch casing

Surface Plug Setting Date: _____ Cut and Cap Date: _____ Number of Days from Setting Surface Plug to Capping or Sealing the Well: _____

*Wireline Contractor: _____

*Cementing Contractor: _____

Type of Cement and Additives Used: _____

Flowline/Pipeline has been abandoned per Rule 1105 ☐ Yes ☐ No

Technical Detail/Comments:

I hereby certify all statements made in this form are, to the best of my knowledge, true, correct, and complete.

Signed: _____ Print Name: Pat Dolezal

Title: Regulatory Specialist Date: 8/24/2022 Email: pat.dolezal@ownresources.com

Based on the information provided herein, this Well Abandonment Report (Form 6) complies with COGCC Rules and applicable orders and is hereby approved.

COGCC Approved: Wolfe, Stephen Date: 8/25/2022

CONDITIONS OF APPROVAL, IF ANY:

Expiration Date: 2/24/2023

Condition of Approval

COA Type**Description****Bradenhead Testing**

Prior to starting plugging operations a bradenhead test shall be performed if there has not been a reported bradenhead test within the 60 days immediately preceding the start of plugging operations.

- 1) If, before opening the bradenhead valve, the beginning pressure is greater than 25 psi, sampling is required.
- 2) If pressure remains at the conclusion of the test, or if any liquids were present during the test, sampling is required.

The Form 17 shall be submitted within 10 days of the test. Sampling shall comply with Operator Guidance - Bradenhead Testing and Reporting Instructions. If samples are collected, copies of all final laboratory analytical results shall be provided to the COGCC within three (3) months of collecting the samples.

If there is a need for sampling, contact COGCC engineering for verification of plugging procedure.

Flowlines

Consistent with Rule 911.a, a Form 27 must be approved prior to cut and cap, conducting flowline abandonment, or removing production equipment. Allow 30 days for Director review of the Form 27; include the Form 27 document number on the Form 44 for offsite flowline abandonment (if applicable) and on the Form 6 Subsequent.

Properly abandon flowlines per Rule 1105. If flowlines will be abandoned in place, include with the Form 27: pressure test results conducted in the prior 12 months as well as identification of any document numbers for a COGCC Spill/Release Report, Form 19, associated with the abandoned line.

	<p>Plugging</p> <p>1) Provide electronic Form 42 Notice of MIRU 2 business days ahead of operations and electronic Form 42 Notice of Plugging Operations 48 hours prior to mobilizing for plugging operations.</p> <p>2) Contact COGCC Area Inspector prior to commencing plugging operations.</p> <p>3) Plugs and squeezes will be placed as stated in the Plugging Procedure section of the approved NOIA unless revised by COA or prior approval from COGCC is obtained.</p> <p>4) The wellbore must be static prior to placing cement plugs which are to be a minimum of 100' in length for all but surface plugs. Mechanical isolation requires a 25' cement plug, minimum. For plugs not specified to be tagged, a tag is required if circulation is not maintained while pumping plug and displacing to depth. Tag at tops specified or shallower. Notify COGCC Area Engineer before adding cement to previous plug with insufficient height.</p> <p>5) Place a 50' plug (minimum) at the surface, both inside the inner most casing and in all annular spaces. Surface plugs shall be circulated to surface. Confirm cement to surface in all strings during cut and cap.</p> <p>6) With the Form 6 SRA operator must provide written documentation which positively affirms each COA has been addressed.</p> <p>7) No current Form 17 on file with COGCC. Contact COGCC area engineer with results of pre-plugging bradenhead test for confirmation of plugging procedure prior to commencing plugging operations.</p> <p>8) After placing the shallowest hydrocarbon isolating plug (1498'), operator must wait a sufficient time on all subsequent plugs to confirm static conditions. If at any time after placing this plug there is evidence of pressure or of fluid migration, contact COGCC Area Engineer before continuing operations.</p> <p>9) Plugging procedure has been modified as follows, Plug #1 - 1498', CIBP with 2 sx of cement. If the surface casing pressure was 0 psi during the pre plugging bradenhead test set Plug #2a, otherwise see COA #7 and then proceed to Plug #2b. Plug #2a - 1100', CIBP with 2 sx of cement. Proceed to Plug #3. Plug #2b - 900', perf and pump 40 sx, leave 10 sx in the casing. WOC for 8 hrs and check surface casing pressure. Notify COGCC Area Engineer of the pressure before proceeding with plugging operations. Plug #3 - 360', perf and circulate 110 sx of cement to surface. WOC and tag at 200' or shallower if cement does not circulate to the surface and remain there. See COA #4. Plug #4 - 50' of cement at the surface in both the casing and the annulus, see COA #5 for placement requirements.</p>
3 COAs	

Attachment List

<u>Att Doc Num</u>	<u>Name</u>
403145375	FORM 6 INTENT SUBMITTED
403145397	WELLBORE DIAGRAM
403145398	WELLBORE DIAGRAM

Total Attach: 3 Files

General Comments

<u>User Group</u>	<u>Comment</u>	<u>Comment Date</u>
Engineer	Groundwater: Ogallala behind surface casing Deepest water well: 300'(1mi, 11 wells) Log: 9/15/2001 125-08377 GR 3846	08/25/2022
OGLA	OGLA review completed.	08/24/2022
Engineer	Requested expedited approval	08/24/2022

Total: 3 comment(s)