



Current and Previously Abandoned Zones

Perforations	Date	Method of Isolation (None, Squeezed, BP, Cement, etc.)	Plug Depth
Jsnd	4925-4930	None	

Casing History

Casing Size	Casing Depth	Cement Top	Stage Cement Top
10 3/4	167	surface	
5 1/2	4974	4252	

Plugging Procedure for Intent and Subsequent Report

CIBP #1: Depth 4960 with 2 sks cmt on top. CIBP #2: Depth \_\_\_\_\_ with \_\_\_\_\_ sks cmt on top. NOTE: Two (2) sacks cement required on all CIBPs.

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in  Casing  Open Hole  Annulus

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in  Casing  Open Hole  Annulus

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in  Casing  Open Hole  Annulus

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in  Casing  Open Hole  Annulus

Set \_\_\_\_\_ sks cmt from \_\_\_\_\_ ft. to \_\_\_\_\_ ft. in  Casing  Open Hole  Annulus

Perforate and squeeze @ \_\_\_\_\_ ft. with \_\_\_\_\_ SKS Leave at least 100 ft. in casing

Perforate and squeeze @ \_\_\_\_\_ ft. with \_\_\_\_\_ SKS Leave at least 100 ft. in casing

Perforate and squeeze @ \_\_\_\_\_ ft. with \_\_\_\_\_ SKS Leave at least 100 ft. in casing

Set 50 SKS 1/2 in 1/2 out surface casing from 220 ft. to 120 ft.

Set 10 SKS @ surface

Cut 4 feet below ground level, weld on plate

Set \_\_\_\_\_ SKS in rat hole

Dry-Hole Marker:  No  Yes

Set \_\_\_\_\_ SKS in mouse hole

Additional Plugging Information for Subsequent Report Only

Casing recovered: \_\_\_\_\_ ft. of \_\_\_\_\_ in. casing. Plugging date: \_\_\_\_\_

\*Wireline contractor: \_\_\_\_\_

\*Cementing contractor: \_\_\_\_\_

Type of cement and additives used: \_\_\_\_\_

\*Attach job summaries.

I hereby certify that the statements made in this form are, to the best of my knowledge, true, correct, and complete.

Print Name: Fayed to Kort Dodge Date: 2/4/99

Signed: \_\_\_\_\_ Title: \_\_\_\_\_ Date: \_\_\_\_\_

OGCC Approved: Ed D. Matter Title: Sr. Engineer Date: 2/19/99

CONDITIONS OF APPROVAL, IF ANY: Contact Ed Binkley 24 hr prior to commencing work

If casing (5 1/2) is not pulled perforate and squeeze 50 sks @ 220' leave 100' inside casing

T.1.1 Check condition of remote Fax. 919708571286

P.1 Feb 4 1999 10:57

\*\* Transmit Conf. Report \*\*