

STATE OF COLORADO
OIL AND GAS CONSERVATION COMMISSION
DEPARTMENT OF NATURAL RESOURCES

File in duplicate for Patented and Federal lands.
File in triplicate for State lands.

5. LEASE DESIGNATION & SERIAL NO.
Dyar #1 55090

6. IF INDIAN, ALLOTTEE OR TRIBE NAME



7. UN
00066679

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR
Reichlinger Business Services

3. ADDRESS OF OPERATOR
P.O. Box 4 York, Nebraska 68467

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.
See also space 17 below.)
At surface

At proposed prod. zone

8. FARM OR LEASE NAME
Dyar 55090

9. WELL NO.
1

10. FIELD AND POOL, OR WILDCAT

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

SE 1/4 13-2N-54W

14. PERMIT NO.
84-1072

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

12. COUNTY
Washington

13. STATE
CO

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL
(Other)

PULL OR ALTER CASING
MULTIPLE COMPLETE
ABANDON
CHANGE PLANS

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)
(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

REPAIRING WELL
ALTERING CASING
ABANDONMENT*


17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

18. Date of work 6-10-88 * Must be accompanied by a cement verification report.

Proposed Plugging Procedure:

1. Dump sand on bridge plug to 10' above perforations.
2. Dump bail 4 sacks cement on sand.
3. Pull production casing.
4. Fill hole with mud up to surface casing.
5. Drop plug to bottom of surface casing.
6. Fill surface casing with cement.
7. Weld plate on top of surface casing (4' below ground level).

FOR OFFICE USE ONLY
ET
RE
UC
SP



19. I hereby certify that the foregoing is true and correct

SIGNED Gregory Reichlinger TITLE Operator DATE 5-31-88

(This space for Federal or State office use)
APPROVED BY J. A. [Signature] TITLE SUPR. PETROLEUM ENGINEER Oil & Gas Cons. Comm. DATE JUN 6 1988

CONDITIONS OF APPROVAL, IF ANY:

X