

STATE OF COLORADO  
OIL AND GAS CONSERVATION COMMISSION  
DEPARTMENT OF NATURAL RESOURCES

File in duplicate for Patented and Federal lands.  
File in triplicate for State lands.

5. LEASE DESIGNATION & SERIAL NO.  
DYAR 55090

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

7. UNI  
00066700

2. NAME OF OPERATOR  
Reichlinger Business Services

8. FARM OR LEASE NAME  
Dyar 55090

3. ADDRESS OF OPERATOR  
PO Box 4, York, Nebraska 68467

9. WELL NO.  
2

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface 1100 FSL & 1940' FEL of SE 1/4  
At proposed prod. zone  
Same as above

10. FIELD AND POOL, OR WILDCAT  
Xenia 'J' Sand

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
SE 1/4 Sec. 13-2N-54W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)  
4537' GR

12. COUNTY  
Washington

13. STATE  
CO

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREAT

MULTIPLE COMPLETE

FRACTURE TREATMENT

ALTERING CASING

SHOOT OR ACIDIZE

ABANDON

SHOOTING OR ACIDIZING

ABANDONMENT\*

REPAIR WELL

CHANGE PLANS

(Other)

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)


17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

18. Date of work 6-10-88

\* Must be accompanied by a cement verification report.

Proposed Plugging Procedure:

1. Dump sand on bridge plug to 10' above perforations.
2. Dump bail 4 sacks cement on sand.
3. Pull production casing.
4. Fill hole with mud up to surface casing.
5. Drop plug to bottom of surface casing.
6. Fill surface casing with cement.
7. Weld plate on top of surface casing (4' below ground level).



19. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Operator

DATE 5-31-88

(This space for Federal or State office use)

APPROVED BY

TITLE

SUPR. PETROLEUM ENGINEER  
Oil & Gas Cons. Comm.

DATE

JUN 6 1988

CONDITIONS OF APPROVAL, IF ANY: